

Adjustable Bows

The adjustable bow cannot join directly to the chute or the sweep. You will need to put a permanent post in between the Bow and the chute and then it will join on without interference. The permanent post would need to be cut to size.

